



de Installationsanleitung
en Installation Instructions
fr Instructions d'installation
it Istruzioni di montaggio
nl Installatiehandleiding
es Instrucciones de Instalación
pt Instruções de instalação
da Installationsvejledning
sv Installation anvisningar

fi Asennusohje
pl Instrukcja instalacji
cs Návod k instalaci
sk Návod na montáž
el Οδηγίες εγκατάστασης
sl Navodila za instalacijo
hu Beépítési útmutató
ru Руководство по установке
tr Montaj talimatı




1




2348Z01

2



2348Z02



3



2348Z03

4


2348Z04





5

2348Z05

- 1 DC 12 V (G+)
- 2 GND (CL-)
- 3 BSB (CL+)



2348Z07



2348Z06

6



<http://siemens.com/bt/download>
 Search: **QAA74..**
 Filter: **your language**

